

Emergency Shower Decontamination Booth

The HEMCO Emergency Shower provides a complete solution to your emergency shower and decontamination needs. Providing a full bodied shower protecting employees and surrounding area.

- ✓ Full body shower and eye wash, both with immediate response activation handle.
- ✓ Transparent strip curtain provide for easy access into booth, while containing contaminated water splash.
- ✓ Durable one piece fiberglass construction with glass smooth white surfaces and covered corners for ease of clean-up. Non-skid surface with self draining basin to 3" drain outlet.
- ✓ Emergency Shower Decontamination Booth is pre plumbed to single point 1 1/4" IPT. connection. Meets ANSI and OSHA

Specifications:

Emergency Drench Shower Booth- molded of white fiberglass and features seamless construction. Unit is equipped with pull rod activated overhead drench shower and rear wall mounted eye/face wash
Cat No. 16601



Accessories:

1. Step Treadle- activated valve system
Cat No. 16690
2. Alarm Horn- audible warning sound when system is actuated.
Cat No. 16680
3. Alarm Light- Visual warning light when system is activated.
Cat No. 16600
4. Portable 300 Gallon- self contained water supply with 30 GPM pump. Convert any of HEMCO's shower booths into a portable shower.
Cat No. 16645
5. Hand Held Body wash- Squeeze valve nozzle on 8' coiled hose. Can be used to rinse all body parts while victim is sitting or lying down.
Cat No. 16005
6. Grab Bars- Support victim and rescue personnel during decontamination.
Cat No. 16620

Visit www.HEMCOcorp.com